

Modified:10/14/2009

SOLID CHANNEL WITH COVER WITH SNAP ON COVER








	part number	size	Н	W	L	cover
e e	00250100xx	2X2	2	2	72	snap-on
Table	00250200xx	4x4	4	4	72	snap-on
ering						
Orde						
0						

SLOTTED CHANNEL WITH COVER


Modified:06/03/2010



part number	size	н	W	L	OW	P	EL	cover
00250300XX	2x2	2	2	72	.75	4	4	snap-on
00250400XX	4x4	4	4	72	1.25	2	4	snap-on


CHANNEL SPLICE WITH COVER

Modified:09/14/2020




	part number	size	Н	W	L
le	00250500xx	2x2	2.4	2.2	5.8
Table	00250501xx	2x2	2.4	2.2	3.4
Ordering	00250600xx	4x4	4.4	4.2	5.8
)rde					
)					

CHANNEL SPLICE ASSEMBLY INSTRUCTIONS



4x4 Channel Splice



2x2 Channel Splice

Channel splice assembly information


system	H1	H2	W1	W2	W3
2X2	2.3	1	2.2	1.1	
4X4	4.3	2	4.2	1.1	2

Typical hardware used on channel splice

item	description	2X2	4X4
1	1/4-20 X 5/8 RHMS	6	8
2	1/4 Helical Spring Flat Washer	6	8
3	1/4 Helical Spring Lock Washer	6	8
4 or	1/4-20 HHN	6	8
5	plastic rivet	6	8

Note:


- $\bullet \quad \hbox{Use channel splice to join the pieces of channel (solid or slotted)}.$
- Separately order hardware kit as needed:
 - A. Ordering number 0025710000 provides plastic rivet.
 - B. Ordering number 0025750010 provides 1/4-20 hardware



<u>Installation instructions:</u>


- Position the end of one channel half way into the channel splice and drill 9/32" Hole (one per side for 2x2 or 4x4,two per side for 4x8) through both components.
- Use 1/4-20 hardware (0025750010) or plastic rivets (002571000) to fasten channel and splice sides. Butt the secondchannel to the first and fasten in a similar manner. Do not leave a gap between channels.
- Drill the bottom and fasten in a similar manner. Use two holes for 2x2, four holes for 4X4 and six holes for 4x8.

FLAT END CAP Modified:10/14/2009



	part number	size	Н	W	L
	00250901xx	2x2	1.1	2.2	2.2
Order					
ō					


END CAP




	part number	size	Н	W	L
	00250900xx	2x2	2.4	2.4	1.5
Order	00251000xx	4x4	4.4	4.4	2.5
Ö					

FIGURE EIGHT ASSEMBLY


Modified:09/22/2009



	part number	size	Н	W	L
rderi	21960900XX	4x4	4.12.	26.50	22.18
Ō					




HORIZONTAL TEE Modified:08/12/2021




	part number	size	Н	W	L	other
le	00251500xx	2x2	2.4	5.35	7.8	
Table	00251600xx	4x4	4.4	8.1	11.1	
Ordering						
rde						
0						

FOUR WAY CROSS Modified:10/14/2009




part number	size	Н	W	L
00251100xx	2x2	2.4	7.83	7.83
00251200xx	4x4	4.4	11.1	11.1
	00251100xx		00251100xx 2x2 2.4	00251100xx 2x2 2.4 7.83

VERTICAL TEE Modified:10/14/2009



	part number	size	Н	W	L
¥	00251700xx	2x2	2.4	5.1	7.8
Order	00251800xx	4x4	4.4	7.7	11.1
U					

DOWN SPOUT





	part number	Size	Н	W	L	other
ole	00251701xx	2x2	2.4	4.9	13.00	width dividers
Table						
Ordering						
rde						
0						

Notes:

Allows for express fibers to by-pass opening and fibers to exit

REDUCER WITH COVER







Modified:10/14/2009

VERTICAL / HORIZONTAL REDUCING TEE

Modified:10/14/2009






	part number	Size	Н	W	L	other
ole	00253600xx	4x4	4.4	7.7	8.87	vertical, with 2x2 outlet
Table	00253700xx	4x4	4.4	7.7	8.87	horizontal, with 2x2 outlet
Ordering						
rde						
0						

DUAL REDUCING HORIZONTAL TEE

Modified:10/14/2009



	Part Number	Size	Н	W	L	A	В	С	other
ole	00252900xx	4x4	4.25	4.25	13.68	2	2.8	2	b=standard spacing
Tabk	00253000xx	4x4	4.25	4.25	15.39	2	4.5	2	b=uffer spacing
ing									
Orderii									
Ō									


Note:

 Includes one cable retainer (0025700200) and its moulding hardware; user installed.

Modified:10/14/2009

DUAL REDUCING VERTICAL TEE






	part number	Size	H1	H2	W1	W2	L
rder	00253800xx	4x4	4.11	2.11	4.11	7.02	13.68
Ō							

90° HORIZONTAL ELBOW


Modified:10/14/2009



	part number	Size	Н	W	L
Table	00251300xx	2x2	2.2	5.35	5.35
	00251400xx	4x4	4.4	8.08	8.08
Ordering					
rde					
0					

90° VERTICAL OUTSIDE DOWN ELBOW


Modified:08/21/2009



	part number	Size	Н	W
Table	00251900xx	2x2	5.2	2.9
	00252000xx	4x4	7.8	5.07
ering				
rdeı				
ō				

90° VERTICAL INSIDE UP ELBOW


Modified:09/04/2009



	part number	Size	Н	W
ole	00252100xx	2x2	5.07	2.9
Table	00252200xx	4x4	7.7	5.07
ering				
rde				
0				

45° VERTICAL OUTSIDE DOWN ELBOW


Modified:10/14/2009



	part number	Size	Н	W	L
ole	00252300xx	2x2	4.5	2.9	3.4
Ordering Table	00252400xx	4x4	7.0	5.07	5.9
ring					
rde					
0					

INSTRUMENT COMPANY


45° VERTICAL INSIDE UP ELBOW



	part number	Size	Н	W	L
əlc	00252500xx	2x2	3.45	2.9	4.6
Ordering Table	00252600xx	4x4	5.9	5.07	7.1
ring					
rde					
0					


45° HORIZONTAL ELBOW






	part number	Size	Н	W	L
Table	00253300xx	2x2	2.9	4.2	2.9
	00253400xx	4x4	4.4	4.4	5.07
Ordering					
rde					
0					

TRANSITIONAL JOG Modified:09/22/2009




	part number	Size	Н	W	L	other
ole	21908400xx	2x2	2.4	5.4	7.3	Lto R
Table	21908401xx	2x2	2.4	5.4	7.3	R to L
Ordering						
rde						
Ō						

INSTANT EXIT Modified:09/22/2009



	part number	Size	L1	L2	Н	W1	W2	W3
ole	21996002xx	2x2	13	2	3.12	2	2	7.25
Tabl	21996004xx	4x4	13	2	3.12	4	2	9.25
Ordering								
rde								
0								


TRUMPET Modified:10/02/2014




Ordering Table

Part Number	Size	Н	W	L
00254600xx	2x2	2.4	5.7	4.0
00254700xx	4x4	3.4	8	6.0

FITTING SPLICE Modified:10/14/2009






	part number	Size	Н	W	L
ole	00252700xx	2x2	1.54	2.0	1.72
Table	00252800xx	4x4	3.5	4.0	3.0
Ordering ⁻					
ge					
Ō					

ENTRY FITTING






	part number	Size	L	Н	D1
ole	21739001xx	2x2	8.8	2.14	2.02
Ordering Table	21739000xx	4x4	10.81	4.14	4.02
ring					
rde					
0					

Note:


Use Entry Fitting Wherever You Need A Fiber Outlet.

ADAPTERS Modified:01/24/2011



	part number	other
ole	00253900xx	adapter kit, 2" square to 1.5" round adapter only
Ordering Table	00253901xx	2" square to 1" round flex
ing	00253902xx	4" square to 2" round flex
rder		•
ō		


FLEX TUBE KIT Modified:10/14/2009



	part number	Α	В	Н	D1
Table	00254900xx	2"	1-1/2"		
Ordering Table					
Orde					

	item	qty.	description
st	1	2	adapter
k List	2	2	rachet clip
Stock	3	1	24" tubing
S			-


F



	Part Number	Туре	н	W	L
5	00254200xx	solid	.875 (22)	1.625 (41)	120 (3048)
Ordering	00254201xx	sloted	.875 (22)	1.625 (41)	120 (3048)
Ord					

INSTRUMENT COMPANY


JUNCTION KIT



	Part Number	Hardware
o o	0025430010	1/4"
Ordering	0025430110	3/8"
Orde		
0		

	Item	Qty	Description
t s	1	1	junction bar
Stock List	2	4	hex head cap screw
toc	3	4	spring nut
0)	4	4	helical spring lock washer
	5	4	flat washer

TEE JUNCTION KIT







	Item	Qty	Description
t s	1	1	junction plate
Stock List	2	5	1/4"-20 x 3/4 hex head cap screw
toc	3	5	1-4"-20 spring nut
S	4	5	1/4"-20 helical spring lock washer
	5	5	1/4" flat washer

CABLE RACK MOUNTING KIT - RAIL/STRUT

Modified:02/26/2010



CABLE RACK MOUNTING KIT - CHANNEL



part number	н	W	channel
0025500310	4.25 (108)	2.9 (74)	2x2
0025500410	4.25 (108)	4.9 (124)	4x4
0025500510	6.78 (172)	2.9 (74)	2x2
0025500610	6.78 (172)	4.9 (124)	4x4


	Item	Qty	Description
ts.	1	1	bracket
k Lis	2	1	5/16-18 x 1hhcs
Stock List	3	ar	10-32 x 1/2" rhms
0)	4	ar	1/4" helical washer
	5	ar	10-32 hhn


Installation Notes

- Attach the bracket to the ladder type cable rack
- Mount the support strut with bolt & sprint nut
- To mount channels or fitting use strut straight bracket mounting kit (0025560110 or 0025560210)

FIBER DUCT CLIP ASSEMBLY








	Item	Qty	Description
st	1	1	10-32 x 3/8" rhms
Stock List	2	1	#10 flat washer
stoc	3	1	fiber duct spring clip
o,			

DETAILA

END ACCESSIBLE THREADED ROD MOUNTING KIT - STRUT

Modified:10/15/2014




	part number	w	threaded rod
6	0025510310	2.85 (72)	1/2"
ering	0025510410	2.85 (72)	5/8"
Ord			

	Item	Qty	Description
ţ	1	1	bracket
ĹĬ	2	1	1/4-20 x 3/4 rhms
Stock List	3	1	1/4 helical washer
o,	4	1	1/4-20 spring nut
	5	2	heavy heax head nut
	6	2	helical spring lock washer

Installation Notes

- Attach the bracket utilizing accessible end of threaded rod.
- Mount the support strut with bolt and spring.
- When mounting a fitting, one 13/64" hole must be drilled in the fitting.

END ACCESSIBLE THREADED ROD MOUNTING KIT - CHANNEL



Mounting Bracket

	part number	W	н	channel	threaded rod
6	0025510510	2	3.8	2x2	1/2
Ordering	0025510610	2	3.8	2x2	5/8
Orde	0025510710	4	5.0	4x4	1/2
Ŭ	0025510810	4	5.0	4x4	5/8
	0025511010	9	5.0	4x4	5/8

	Item	Qty	Description
	1	1	bracket
st	2	ar	10-32 x 1/2" rhms
Stock List	3	ar	10 helical spring lock washer
toc	4	ar	10-32 hhn
0)	5	2	heavy hex nut
	6	2	helical spring lock washer


- w	

Installation Notes

- Attach the bracket utilizing accessible end of threaded rod
- Mount channel or fitting with 10-32 hardware
- When mounting a fitting, one 13/64" hole must be drilled in the fitting.

THREADED ROD MOUNTING KIT - STRUT





	part number	w	threaded rod
5	0025520210	5.2	5/8
Ordering	0025520310	2.85	1/2"
Ç	0025520410	2.85	5/8"


	Item	Qty	Description
st	1	1	bracket
k Lis	2	1	1/4-20 rhms
Stock List	3	1	1/4 helical washer
σ	4	1	1/4-20 spring lock washer
	5	2	split hex nut

Installation Instructions:

- Place lower split nut on the rod at desired level.
- Position bracket and place second split nut directly above the bracket. To place nuts, rotate top and bottomof nut sections until cut-outs are aligned, place nut and rotate top section1/3 turn. Tighten nut in normal manner without separately tightening top section against bottom section of nut.
- Mount the support strut with bolt and spring nut.
- To mount channels or fittings use strut straight bracket mounting kit (0025560110 or 0025560210).

THREADED ROD MOUNTING KIT - CHANNEL

Mounting Bracket



2x2 With Cover


_					
	part number	н	W	channel	threaded rod
	0025520510	2 (51)	3.8 (97)	2x2	1/2"
L	0025520610	2 (51)	3.8 (97)	2x2	5/8"
	0025520710	4 (102)	5 (127)	4x4	1/2"
	0025520810	4 (102)	5 (127)	4x4	5/8"

	Item	Qty	Description
	1	1	bracket
List	2	ar	10-32 x 1/2" rhms
Stock List	3	ar	helical spring lock washer
Stc	4	ar	10-32 hhn
	5	2	slip nut

F

Installation Instructions:

- Place lower split nut on the rod at desired level.
- Position bracket and place second split nut directly above the bracket. To place nuts, rotate top and bottom of nut sections until cut-outs are aligned, place nut and rotate top section 1/3 turn. Tighten nut in normal man ner without separately tightening top section against bottom section of nut.
- Mount channel or fitting with 10-32 hardware.
- When mounting a fitting, one or two 13/64" holes must be drilled in the fitting.



1/2"

5/8"

threaded rod

1/2"

5/8"

1/2"


5/8"



pa

0025530310

0025530410



2.85 (72)


2.85 (72)

	lk - ···	Ohr	Description
	Item	Qty	Description
	1	1	bracket
	2	1	1/4-20 rhms
ist	3	1	1/4 helical washer
Stock List	4	1	1/4-20 spring lock washer
Sto	5	4	heavy hex nut
	6	4	helical spring lock washer
	7	2	parallel auxiliary framing clip

Installation Instructions:

- Attach threaded rod to the parallel auxiliary bar.
- Install mounting bracket at desired position.
- Mount the support strut with bolt and spring nut.
- To mount channels or fittings use strut straight bracket mounting kit (0025560110 or 0025560210).

AUXILIARY FRAMING BAR THREADED ROD MOUNTING KIT - CHANNEL



Installation Instructions:

- Attach threaded rod to the parallel auxiliary bar.
- Install mounting bracket at desired position.
- Mount 2x2 or 4x4 channel or fitting with 10-32 hardware.
- When mounting a fitting, one or two 13/64" holes must be drilled in the fitting.

10-32 x 1/2" rhms 10 helical spring lock washer 10-32 heavy hex nut heavy hex nut

6

2x2

2x2

4x4


4x4

helical spring lock washer

parallel auxiliary framing clip

AUXILIARY FRAMING CHANNEL THREADED ROD MOUNTING KIT - STRUT

Modified:03/02/2010




	part number	w	threaded rod
50	0025540310	2.85 (72)	1/2"
Ordering	0025540410	2.85 (72)	5/8"
Ord			

	Item	Qty	Description
	1	1	bracket
	2	1	1/4-20 x 3/4 rhms
List	3	1	1/4 helical spring lock washer
Stock List	4	1	1/4-20 spring nut
Stc	5	4	heavy hex nut
	6	4	helical spring lock washer
	7	2	parallel auxiliary framing clip

Installation Instructions:

- Attach threaded rod to the parallel auxiliary channel.
- Attach the mounting bracket at the desired position.
- Mount the support strut with bolt and spring nut.
- To mount channels or fittings use strut straight bracket mounting kit (0025560110 or 0025560210).

AUXILIARY FRAMING CHANNEL THREADED ROD MOUNTING KIT - CHANNEL



part number	Н	W	channel	threaded rod
0025540510	2 (51)	3.8 (97)	2x2	1/2"
0025540610	2 (51)	3.8 (97)	2x2	5/8"
0025540710	4 (102)	5 (127)	4x4	1/2"
0025540810	4 (102)	5 (127)	4x4	5/8"


	Item	Qty	Description
	1	1	bracket
	2	ar	10-32 x 1/2" rhms
List	3	ar	10 helical spring lock washer
Stock List	4	ar	10-32 heavy hex nut
Stc	5	4	heavy hex nut
	6	4	helical spring lock washer
	7	2	parallel auxiliary framing clip

Installation Instructions:

- Attach threaded rod to the parallel auxiliary channel.
- Attach the mounting bracket at the desired position.
- Mount the support rail with 1/4-20 hardware.
- When mounting a fitting, one or two 13/64" holes must be drilled in the fitting.

UNEQUAL FLANGE EQUIPMENT RACK (UFER) CENTER TOP MOUNTING KIT - STRUT






	part number	W	threaded rod
Ordering	0025550210	2.85 (72)	5/8"

	Item	Qty	Description
	1	1	bracket
st	2	1	1/4-20 x 3/4 rhms
Stock List	3	1	1/4 helical spring lock washer
toc	4	1	1/4 spring nut
0)	5	3	5/8-11 hhn
	6	3	5/8 helical spring lock washer

Installation Instructions:

- Add nut and lock washer to one end of threaded rod.
- Install the rod into the top center of equipment rack and tighten the nut.
- · Using other two nuts and lock washers attach the mounting bracket at the desired position.
- Mount the support rail with bolt and spring nut.
- To mount channels or fittings use strut straight bracket mounting kit (0025560110 or 0025560210).

UNEQUAL FLANGE EQUIPMENT RACK (UFER) CENTER TOP MOUNTING KIT - CHANNEL



part number	н	W	threaded rod	channel
0025550310	2 (51)	3.8 (97)	5/8"	2x2
0025550410	4 (102)	5.0 (127)	5/8"	4x4

	Item	Qty	Description
	1	1	bracket, short
;t	2	1	bracket, long
Stock List	3	ar	10-32 x 1/2" rhms
tocl	4	ar	10 helical spring lock washer
S	5	ar	10-32 hhn
	6	ar	5/8 hhn

0025550310 Installation Instructions:

- Add nut and lock washer to one end of threaded rod.
- Install the rod into the top center of equipment rack and tighten the nut.
- Using other two nuts and lock washers attach the mounting bracket at the desired position.
- Mount 2x2 channel or fitting with 10-32 hardware.
- When mounting a fitting, one 13/64" hole must be drilled in the fitting

0025550410 Installation Instructions:

- Add nut and lock washer to one end of threaded rod.
- Install the rod into the top center of equipment rack and tighten the nut.
- Using other two nuts and lock washers attach the mounting bracket at the desired position.
- Mount 4x4 channel or fitting with 10-32 hardware.
- When mounting a fitting, two 13/64" holes must be drilled in the fitting.

Е




STRUT STRAIGHT BRACKET MOUNTING KIT - CHANNEL

Phone: (919) 575-6426

Fax: (919) 575-4708 www.eNewton.com

Modified:03/02/2010



	part number	Н	W	channel
5	0025560110	3	5.0	2x2
Ordering	0025560210	5	6.0	4x4
Örd	0025560310	5	10.0	4x8

	Item	Qty	Description
	1	1	bracket
	2	1	1/4-20 x 3/4 rhms
List	3	ar	1/4 helical spring lock washer
Stock List	4	ar	heavy hex nut
Stc	5	1	1/4-20 spring nut
	6	ar	helical spring lock washer
	7	ar	rhms

W

6.0

6.0

6.0

Description bracket

12-24 x 1/2 rhms

10-32 x 1/2 rhms

10-32 hhn

1/2 helical spring lock washer

10 helical spring lock washer

Installation Instructions:

Attach the bracket to the channel two feet from the previous support point.

part number

0025570110

0025570210

0025570310

Attach the assembly to the strut with the spring nut and bolt.

UNEQUAL FLANGE EQUIPMENT RACK (UFER) HORIZONTAL MOUNTING KIT - CHANNEL


Modified:10/14/2009


channel

2x2

2x2

4x4





0025570210

0025570210: Installation Instructions:
Attach the bracket to the equipment rack flange with two 12-24 screws.
 Install 2x2 channel or fitting using 10/32 hardware.

When mounting a fitting, one 13/64" hole must be drilled in the fitting. 0025570310: Installation Instructions:

Н

5)

4

6

Qty

2

ar

Item


2

4

- Attach the bracket to the equipment rack flange with two 12-24 screws.
- Install 4x4 channel or fitting using 10/32 hardware.
- When mounting a fitting, two13/64" holes must be drilled in the fitting.


246

Modified:10/14/2009



	part number	channel
6	0025580110	2x2
ering	0025580210	4x4
Orde		
0		

	Item	Qty	Description
	1	2	bracket
妆	2	2	12-24 x 1/2 rhms
Stock List	3	2	12 helical spring lock washer
itoc	4	1	12-24 hhn
0,	5	ar	10-32 x 1/2 rhms
	6	ar	10 helical spring lock washer
	7	ar	10-32 hhn



0025580110: Installation instructions:


- Install one I-bracket to the equipment rack front or rear upright. Distance between brackets should be Approximately two feet.
- Attach the second bracket to the first selecting the arrangement that provides the desired offset From the equipment rack.
- Install 2x2 channel with one 10-32 screw for each bracket.

0025580210: Installation instructions:

- Install one I-bracket to the equipment rack front or rear upright. Distance between brackets should be approximately two feet.
- Attach the second bracket to the first selecting the arrangement that provides the desired offset from the equipment rack.
- Install 4x4 channel with two 10-32 screws for each bracket.

RAISED FLOOR STANCHION HANGER KIT


Modified:09/22/2009




	part number	Н	W
Ordering	21851300xx	3.5	12.2
Orde			

	Item	Qty	Description
	1	1	unistrut end cap
Ħ	2	4	1/4-20 wing nut
Stock List	3	4	1/4-20 x 2-1/2 hhcs
toc	4	4	1/4 ext. tooth washer
S	5	1	raised floor stantion bracket
	6	1	raised floor stantion weldment


CABLE RETAINER Modified:03/02/2010





	part number	Н	W	L	Channel
5	00257001xx	1.5	1.82	.75	2x2
Ordering	00257002xx	3.38	3.75	.75	4x4
rde					
0					

HARDWARE KIT Modified:10/14/2009




	part number
ĝ	0025710000
derin	
ŏ	

	Item	Qty	Description
);	1	100	plastic rivets
Stock List			
toc			
S			

Modified:01/23/2017

FIBER CAUTION LABEL (ADHESIVE BACKED)





Black, White And Orange Lettering On Adhesive Backed Material

	Part Number	Qty
Ordering	0025730000	1
	0025730100	10
	0025730200	25
	0025730300	50
	0025730400	100

INSTRUMENT COMPANY

FLEX BRACKET Modified:09/22/2009






	part number	Н	W	L
Ordering	21631800xx	1.5	3.75	3.75
Ord				

FLEX BRACKET KIT

Modified:10/14/2009



	part number	Н	W	L
ring	00258302xx	1.5	3.75	3.75
Ordering				

	Item	Qty	Description
χţ	1	1	flex tube ratchet kit
Stock List	2	1	1-1/2 flex tubing
toc	3	1	flex bracket
S	4	4	plastic revit



NOTES: